




TRIANCO

INSTALLATION AND OPERATING INSTRUCTIONS

TRO EVOLUTION ACCU



Index

1.	PRESENTATION	4
2.	DESCRIPTION OF COMPONENTS	5
3.	CONTROL ELEMENTS	6
4.	INSTALLATION INSTRUCTIONS	7
4.1	LOCATION	7
4.2	HYDRAULIC INSTALLATION	7
4.3	ELECTRICAL CONNECTION	8
4.4	FUEL INSTALLATION	8
4.5	COMBUSTION PRODUCTS EXHAUSTION	8
4.6	ANTI-LEGIONELLA FUNCTION	9
4.7	INSTALLING HEATING CIRCUIT 2 (OPTIONAL)	9
5.	COMBUSTION PRODUCTS EXHAUSTION	10
5.1	COMBUSTION PRODUCTS EXHAUSTION AND AIR INTAKE DUAL-DUCT DEVICE Ø80/ Ø100(TYPR C ₅₃)	10
5.2	DOUBLE CONDUIT TO COAXIAL EXHAUSTION TRANSFORMATION (ONLY FOR TRO EVOLUTION 20/30 INC DHW ACCU)	11
5.3	COMBUSTION PRODUCTS EXHAUSTION AND AIR INTAKE HORIZONTALLY-ARRANGED COAXIAL DEVICE Ø80-125 (TYPE C ₁₃) (ONLY FOR TRO EVOLUTION 20/30 INC DHW ACCU)	12
5.4	COMBUSTION PRODUCTS EXHAUSTION AND AIR INTAKE VERTICALLY-ARRANGED COAXIAL DEVICE Ø80-125 (TYPE C ₃₃) (ONLY FOR TRO EVOLUTION 20/30 INC DHW ACCU)	13
6.	FILLING THE INSTALLATION	15
7.	DRAINING THE BOILER	15
8.	SHUTTING DOWN THE BOILER	15
9.	FIRST START-UP	15
10.	INSTALLATION DELIVERY	15
11.	DIGITAL DISPLAY	16
12.	TEMPERATURE SELECTION	18
12.1	SELECTING THE BOILER SETPOINT TEMPERATURE	18
12.2	SELECTING THE DHW SETPOINT TEMPERATURE IN THE HOT WATER TANK	18
13.	OPERATION	19
13.1	HEATING FUNCTION	19
13.2	FUNCTION FOR DHW PRODUCTION BY STORAGE	19
13.3	HEATING CIRCUIT 2 FUNCTIONING (OPTIONAL)	19
14.	ADDITIONAL FUNCTIONS	20
14.1	PUMPS ANTI-BLOCK FUNCTION	20
14.2	ANTI-FROST FUNCTION	20
14.3	BOILER PRESSURE SENSOR FUNCTION	20
14.4	TELEPHONE RELAY CONNECTION	20
14.5	ROOM THERMOSTAT CONNECTION	20
14.6	ANTI-LEGIONELLA FUNCTION (OPTIONAL)	21
14.7	KEYPAD BLOCK FUNCTION	21
15.	E20 REMOTE CONTROL (OPTIONAL)	21
15.1	FUNCTIONING WITHOUT AN OUTDOOR SENSOR	22
15.2	FUNCTIONING WITH AN EXTERNAL SENSOR (OPTIONAL)	22
15.3	DHW MODE FUNCTIONING	22
15.4	TELEPHONE RELAY FUNCTION	22
16.	SAFETY CUT-OUTS	23
16.1	TEMPERATURE SAFETY CUT-OUT	23
16.2	BURNER CUT-OUT	23
16.3	LOW PRESSURE CUT-OUT	23
17.	BOILER MAINTENANCE	24
17.1	CLEANING THE BOILER	24
17.2	ANTI-FROST PROTECTION	25
17.3	BOILER WATER CHARACTERISTICS	25
18.	CIRCULATING PUMPS FLOW CURVES	26
18.1	CHARACTERISTIC CURVES OF THE PUMP	26
18.2	REGULATION OF THE CIRCULATION PUMP	26
18.3	PRESSURE DROP	26
19.	DIMENSIONS	27
19.1	TRO EVOLUTION ACCU	27
20.	TECHNICAL DATA	28
21.	ELECTRICAL DIAGRAM	29
22.	ELECTRICAL CONNECTION DIAGRAM	30
22.1	TRO EVOLUTION ACCU	30
23.	ALARM CODES	31
24.	BURNER	33
24.1	ASSEMBLY	33



TRIANCO

24.2 BURNER START UP	33
24.3 COMBUSTION ADJUSTMENT.....	33
24.4 OIL PRESSURE ADJUSTMENT.....	35
24.5 PIPE PREPARATION	35
24.6 OIL SUPPLY PIPING DIAGRAMS	35
24.7 TECHNICAL SPECIFICATIONS.....	36
24.8 OPERATING CURVES	37
24.9 NOZZLES.....	37
24.10 OIL FLOW VERSUS NOZZLE AND PUMP PRESSURE	37
24.11 ELECTRICAL CONNECTION DIAGRAM	38
24.12 QUICK CONNECTOR	39
24.13 BURNER CONTROL OPERATING SEQUENCE	39
25. FAILURES.....	41
26. SPARE PARTS LIST	43
27. WARRANTY CONDITIONS.....	46

1. PRESENTATION

Thank you for choosing a **TRIANCO** heating boiler. You have chosen a boiler that, with a suitable hydraulic installation and using oil for fuel, will provide the ideal level of comfort for your home.

This manual forms an essential part of the product and it must be given to the user. Read the warnings and recommendations in the manual carefully, as they contain important information on the safety, use and maintenance of the installation.


These boilers must be installed by qualified personnel only, in accordance with the legislation in force and following the manufacturer's instructions.

The start-up of these boilers and any maintenance operations must only be carried out by Official Technical Assistance Services of **TRIANCO**.

Incorrect installation of these boilers could result in damage to people, animals or property, and the manufacturer will hold no liability in such cases.


TRIANCO informs all parties concerned that, in compliance with section 1 of the first additional provision of Law 11/1997, the responsibility for delivering packaging waste or used packaging for its proper environmental management will be that of the final owner of the product (Article 18.1 Royal Decree 782/1998). At the end of its useful life, the product must be taken to a selected collection point for electrical and electronic equipment or must be returned to the distributor at the time of purchasing a new equivalent appliance. For more detailed information on the collection schemes available, contact either the collection facilities of the local authority or the distributor where the purchase was made.

2. DESCRIPTION OF COMPONENTS



- | | |
|---|---------------------------------|
| 1. Cast iron body. | 11. Heating expansion vessel. |
| 2. Stainless steel Condenser. | 12. DHW expansion vessel. |
| 3. Safety valve. | 13. Disconnector Robofil. |
| 4. Automatic air vent. | 14. Heating pump. |
| 5. DHW storage tank. | 15. Boiler temperature sensors. |
| 6. Pressure & Temperature relief valve. | 16. DHW pump. |
| 7. DHW Inlet group. | 17. Drainage valve. |
| 8. DHW recirculation connection. | 18. Balance flue burner. |
| 9. DHW temperature sensor. | |
| 10. Pressure sensor. | |

3. CONTROL ELEMENTS



19. Digital display:

This is the boiler functioning display, on which all the operating information, settings and values appear. In standard operating mode (default display), the actual boiler temperature is shown. If any malfunctioning should occur, the corresponding alarm code will appear on the digital display.

20. Boiler temperature touch button:

This is used to select the boiler setpoint temperature. If **oFF** is selected, the heating function is disabled. To select the desired temperature, simply place your finger on the "+" or "-" symbols on the touch button to increase or decrease the desired boiler temperature.

21. MODE touch button:

When this button is touched the different boiler temperatures appear on the digital display.

22. ON touch button:

If you place your finger on this button for 1 second the boiler will switch on or off.

23. RESET touch button:

If the boiler is in lock-out mode as the alarm has been triggered, touch the RESET button to reset the lock-out and restore functioning. If you are modifying any of the settings or browsing the user menu, you may touch the RESET button to exit the menu WITHOUT SAVING and return to the previous menu level.

24. DHW temperature touch button:

This is used to select the setpoint temperature for domestic hot water. If **oFF** is selected, the heating function is disabled. To select the desired temperature, simply place your finger on the "+" or "-" symbols on the touch button to increase or decrease the desired DHW temperature.

4. INSTALLATION INSTRUCTIONS

The boiler must be installed by personnel authorised by the Department of Industry in accordance with the applicable regulations and standards in force. However, the following recommendations must be complied with when installing the boiler:


4.1 Location

The boiler must be installed in a sufficiently ventilated site. **The boiler must be accessible from the side** for maintenance purposes.

4.2 Hydraulic installation

The hydraulic installation must be made by qualified personnel. The applicable installation legislation is to be complied with, and the following recommendations should also be taken into account.

- The hose connected to the T&P and the pressure relief valve are installed on a provisional basis. The discharge pipes should be fitted in accordance with the current edition of the Building Regulations.
- The inside of the installation piping should be thoroughly cleaned before switching on the boiler.
- We recommend inserting cut-off valves between the installation piping and the boiler to simplify maintenance tasks.
- If the boiler is installed at a lower height than the heating installation, it is recommendable to create a siphon at the boiler outlet, to prevent the installation from heating up due to natural convection when heating is not required.
- Before starting up the unit, it is essential to install the condensation siphon supplied with the boiler documentation on the condensation drain tube on the back of the boiler.
- **The condensation pipe should lead to a drain outlet**, as the Evolution boiler is a condensation boiler and a large amount of water may be generated. This connection should be made in accordance with the regulations for draining off condensation water to the drain network.
- Fill the siphon with water before starting up the unit, to prevent fumes coming out of it.
- We recommend that users periodically check the pressure level and temperature of the storage tank, as well as the condition of the valves, fittings and accessories. In case of flow absence or reduced flow, clean the filter in base of Pressure Reducing Valve (included in the Inlet Group).



IMPORTANT: Installation must be carried out as described in this installation guide with reference to this section where appropriate. This will ensure compliance with Building Regulations, IEEE Regulations and Telford Copper Cylinders warranty provisions.

4.3 Electrical connection

The boiler is equipped for connection at 230 V~, 50 Hz to terminals **1** and **2** of terminal strip **J1** (see "*Electrical Connection Diagram*"). **Remember to earth the appliance.**

The boiler has two terminal strips, **TA₁** (J5) and **TA₂** (J7) for connecting room thermostats or room chronothermostats (see "*Electrical Connection Diagram*") for remote control of heating circuits n° 1 and n° 2 respectively. To correctly connect the room thermostats, firstly remove the bridge joining the terminals of terminal strip **TA₁**. For connection to **TA₂**, simply connect the thermostat to the terminal strip.

4.4 Fuel installation

The model **TRO Evolution Accu.** is supplied with a balanced flue oil burner **Domestic (18)** (see the model in the "Technical Data"). For a correct oil line installation proceed in accordance with the burner instructions enclosed in this manual (see Burner). The oil line installation and the start up operation of the burner has to be carried out by qualified personnel staff.

4.5 Combustion products exhaustion

The installation of exhaustion of the products of combustion has to be carried out by qualified personnel staff and it will fulfil the requirements demanded in the legislation and effective regulatory schemes.


The **TRO Evolution Accu.** boilers are balanced flue oil boilers, so that the combustion products exhaustion is carried out by means of an outlet duct and an air intake from outside. It is recommended that the position at the exhaustion duct exterior portion should be in accordance with the data of the following figures and table:

Position of the exhaustion duct	Minimum distance mm
A under a cornice	300
B between two horizontally-arranged ducts	1000
C from a next window	400
D between two vertically-arranged ducts	1500
E from a next venting grid	600
F under a balcony (*)	300
G under a window	600
H under a venting grid	600
I from a break back of a building	300
J from an angle of a building	300
K from the floor level	2500
L from a vertically/horizontally-arranged outlet or pipe (**)	300
M from a front surface at a distance of 3 metres from the exhaust gas outlet	2000
N like the previous one, but with opening	3000

(*) In so far the balcony width does not exceed 2000 mm.

(**) If the pipe constructive materials were sensitive to the action from the flue gases, this distance should be longer than 500 mm.

ATTENTION: All the fittings used in the combustion products exhaustion and air intake are to be those supplied by TRIANCO firm.



4.6 Anti-legionella function

The **TRO Evolution Accu.** boiler has a legionella prevention function that can be enabled for the domestic hot water in the tank.

This function must be activated by sufficiently qualified personnel. The function is enabled by changing the boiler model selectors on the display card inside the control panel.

Before carrying out any work on the inside of the boiler, **unplug it from the mains**. To activate the anti-legionella function, remove the top cover of the boiler then remove the lid of the control panel box using a screwdriver to remove the two screws holding it in place. When this cover has been removed the electronic circuit board of the display, containing the programming switches, can be accessed.

Select the anti-legionella function by turning **selector 4** to **ON** (see "Electrical Diagram").

4.7 Installing heating circuit 2 (Optional)

All the models in the **TRO Evolution Accu.** range of boilers are supplied with a circulation pump connected to heating circuit 1 (BC₁). In addition to this circuit, all the models are designed to control a second heating circulation pump in a second heating circuit (circuit 2, BC₂).

The hydraulic installation of heating circuit 2 should be made using the **optional flow circuit (IC')** on the rear of the boiler (see "Diagrams and Measurements").

The circulation pump installed in heating circuit 2 must be electrically connected between terminals N and 6 on the supply connector block **J2** (see "Electrical Connection Diagram").


5. COMBUSTION PRODUCTS EXHAUSTION

5.1 Combustion products exhaustion and air intake dual-duct device Ø80/ Ø100(typr C₅₃)


In this type, the combustion products exhaustion and air intake are carried out with separated pipes of Ø80/Ø100mm. by Kits Ø80/Ø100 code CGAS000265. It is the default type of exhaustion for **TRO Evolution Accu.** boilers.

The **maximum length** of pipe that can be installed is 12 metres (TRO Evolution 40 Inc DHW Accu) and 15 metres (TRO Evolution 20/30 Inc DHW Accu), which is the result from adding the pipe metres for the air intake and those of the combustion products exhaustion. Each elbow of 90°, or two of 45°, reduces the available length by 1 metre and 1 metre in horizontal, reduces the available length by 2 metres.

It is recommended that the flue gases outlet pipe be fitted slightly upwardly-inclined 2° to 3° thus preventing water and condensate projections from being ejected outside.




Installation examples:



5.2 Double conduit to coaxial exhaustion transformation (Only for TRO Evolution 20/30 Inc DHW Accu)


The boiler **TRO Evolution Accu.** is given prepared for the exhaustion of the products of combustion and air intake by means of the system of double conduit of Ø100/Ø80. When you want to carry out the exhaustion of combustion gases by means of coaxial tube of Ø80/125, you will use for it a Kit adaptor for coaxial tube Ø80/125 (given under order) Code CGAS000213 + CGAS000222.



The transformation will be able to realize with two different mounting setups:

1. Back exit: it will be enough with disassembling the combustion air intake of the boiler, unscrewing the three screw, mount the adaptor in the exit of flue gases of the boiler backwards and using the flexible tube of entry of air, connect it to the adaptor.
2. Lateral or upwards exit: it will be realized in the same way, but to mount the adaptor kit laterally it is necessary to mount an elbow of 90° Ø80 (code CGAS000147), before the adaptor in the exit of flue gases.

In the following pictures they can observe both setups:




5.3 Combustion products exhaust and air intake horizontally-arranged coaxial device Ø80-125 (type C₁₃) (Only for TRO Evolution 20/30 Inc DHW Accu)


The combustion products exhaust and air intake can be carried out through concentric pipes of Ø80 mm. for the combustion products exhaust and Ø125 mm. for the air intake by means of the horizontally-arranged outlet Kit 1m Ø80-125 code CGAS000189.

The **maximum horizontal length** counted from the boiler, including the kit end, is 6 metres (TRO Evolution 30 Inc DHW Accu) and 8 metres (TRO Evolution 20 Inc DHW Accu). Each elbow of 90°, or two of 45°, reduces the available length by 1 metre.

It is recommended that the flue gases outlet pipe be fitted slightly upwardly-inclined 2° to 3° thus preventing water and condensate projections from being ejected outside.




Installation examples:




5.4 Combustion products exhaust and air intake vertically-arranged coaxial device Ø80-125 (type C₃₃) (Only for TRO Evolution 20/30 Inc DHW Accu)

The combustion products exhaust and air intake can be carried out through concentric pipes of Ø80 mm. for the combustion products exhaust and Ø125 mm. for the air intake, by means of the vertically-arranged outlet Kit Ø80-125 code CGAS000231.

The **maximum vertical length** counted from the boiler, including the kit end, is 7 metres (TRO Evolution 30 Inc DHW Accu) and 10 metres (TRO Evolution 20 Inc DHW Accu). Each elbow of 90°, or two of 45°, reduces the available length by 1 metre.



Installation examples:



6. FILLING THE INSTALLATION

To fill the installation, open the fill valve **(13)** until a pressure of 1 - 1.5 bars appears on the "*boiler pressure*" setting on the display. The circuit should be filled slowly and with the automatic air bleed valve cap **(4)** loose, to let the air out of the installation. The air should also be bled from the rest of the installation using the air bleed valves provided. When the installation has been filled, close the fill valve.

TRO Evolution Accu. boilers have a pressure sensor **(10)** for controlling the pressure of the installation. If the installation pressure drops below a minimum of 0.5 bar, the boiler will not switch on and a low pressure alarm will appear on the display ("**AP**").

NOTE: Switching on the boiler with no water inside could result in serious damage.

7. DRAINING THE BOILER

The water is drained from the boiler by opening the air drain valve **(17)** inside the boiler (on the lower right hand side on opening the door). Connect a flexible tube to this valve and run it to a drain. After draining the boiler, close the valve again and remove the flexible tube.

8. SHUTTING DOWN THE BOILER

To switch off the boiler, place your finger on the power touch button **(22)** for 1 second. In **Off mode**, while the boiler is plugged into the mains and connected to the fuel installation, its heating and DHW functions will be switched off but the anti-frost protection and pump anti-block functions will remain activated.

To shut down the boiler functioning completely, unplug it from the mains and cut off the fuel supply.

9. FIRST START-UP

For the **guarantee to be valid**, the boiler must be started up for the first time by an **official TRIANCO Technical Assistance Service**. Before beginning start-up, the following must be complied with:

- The boiler must be electrically connected to the mains.
- The installation must be filled with water (1 - 1.5 bar must be indicated on the digital display).
- Fuel must be reaching the burner at a pressure of no more than 0.5 bar.


10. INSTALLATION DELIVERY

After the initial start-up, the Technical Assistance Service will explain to the user how the boiler functions, making any observations they consider relevant.

The installer is responsible for clearly explaining to the user the functioning of any control or regulation device forming part of the installation but not supplied with the boiler.






11. DIGITAL DISPLAY


The **TRO Evolution Accu.** boiler is electronic and includes a digital display **(19)** showing the actual temperatures, the setpoint temperatures and the pressure of the installation. In standby mode, the actual boiler temperature in °C is shown on the display. The rest of the available display options can be browsed by touching the MODE button below the display, as follows:



Repeatedly place your finger on the MODE touch button to select the different display options. When the desired option has been selected, it will return to standby after 20 seconds have elapsed.

The following table shows the different display options: :


	Standby. The actual boiler temperature is shown.
	Actual boiler temperature.
	Actual Domestic Hot Water temperature.
	Actual flow temperature of the underfloor heating installation. (option SRX2/EV only)
	Boiler setpoint temperature selected using the corresponding touch button (20) .




Underfloor heating installation flow setpoint temperature selected using the corresponding touch button (20).
(option SRX2/EV only)



DHW setpoint temperature selected using the corresponding touch button (24).




Actual boiler pressure, measured by the Pressure Sensor (10).



Indication of the heating demand status of each circuit connected to the boiler.




Setpoint of the heating pump speed BC₁.



The desired display contrast can be adjusted using the touch button on the right of the display (24).

12. TEMPERATURE SELECTION

12.1 Selecting the boiler setpoint temperature




The desired boiler operating temperature is selected using the touch button, as shown in the figure. To select the desired temperature, touch the "+" or "-" symbols to increase or decrease the temperature respectively. When the temperature has been selected, the display will return to standby mode after a few seconds.

The boiler setpoint temperature can also be selected by using the MODE touch button to browse to the "*boiler setpoint temperature*" display option. When the display shows this option, touch the "+ /-" symbols to select the desired temperature.

If you wish to totally disable the boiler heating function (**Summer** mode), select the setpoint value "**OFF**" by touching the "-" symbol until this value appears on the display.

The permitted boiler setpoint temperature range is OFF and 30 - 85 °C. **TRO Evolution Accu.** model boilers are condensing boilers. In order to obtain maximum boiler performance and energy savings, it is therefore recommended to select a setpoint temperature of 55-70 °C, providing this is permitted by the heating system installed and the insulation conditions of your home.

12.2 Selecting the DHW setpoint temperature in the hot water tank



The desired DHW temperature is selected using the touch button, as shown in the figure. To select the desired temperature, touch the "+" or "-" symbols to increase or decrease the temperature respectively. When the temperature has been selected, the display will return to standby mode after a few seconds. The DHW setpoint temperature range permitted is OFF and 15 - 65 °C.

The DHW setpoint temperature can also be selected by using the MODE touch button to browse to the "*DHW setpoint temperature*" display option. When this option appears on the display, touch the "+ /-" symbols to select the desired temperature.

If you wish to totally disable the boiler's DHW production function, select the setpoint value "OFF" by touching the "-" symbol until this value appears on the display.

13. OPERATION

The **TRO Evolution Accu.** boiler is designed to heat a heating installation and provide domestic hot water. Optionally, a second heating circuit, heating circuit 2, may be connected to the installation to improve its performance.

13.1 Heating Function

In this mode, select the desired boiler setpoint temperature (see "*Selecting the boiler setpoint temperature*") and the temperature of room thermostat 1 (**TA1**) or remote control **E20** (if the boiler is equipped with these). The burner and the heating pump of circuit 1 (**BC₁**) will begin to function until the installation reaches the selected boiler setpoint temperature (or the temperature on room thermostat, if the unit has one). When the temperature of the installation drops below the selected boiler temperature, the burner will start up again, running the heating cycle.

If the DHW temperature in the boiler's integrated hot water tank is lower than the DHW setpoint temperature selected, the heating function will cut out and priority will be given to domestic hot water production, starting up the hot water tank feed pump.

The boiler heating function can be totally disabled (**Summer** mode) by selecting "OFF" as the boiler setpoint value. In this operating mode, only the DHW production function will remain enabled, providing there is a DHW tank connected to the boiler.

NOTE: When the heating function is disabled, circuit 2 will also be disabled if it is connected.

13.2 Function for DHW production by storage

In this mode, select the desired DHW setpoint temperature (see "*Selecting the DHW setpoint temperature*"). The burner and the DHW pump will switch on. When the hot water tank reaches the selected DHW setpoint temperature, it is ready to heat up the heating installation, if it is enabled.

If you wish, you may totally disable the domestic hot water production function by selecting "OFF" as the DHW setpoint temperature.

13.3 Heating circuit 2 functioning (Optional)

All the models in the **TRO Evolution Accu.** range of boilers have the option of controlling a second heating circuit. This requires the installation of a second circulation pump on the boiler. To correctly install this pump, carefully follow the instructions given in the "Installing heating circuit 2" section of this manual.

Heating circuit 2 will work with the selected boiler setpoint temperature (see "*Selecting the boiler setpoint temperature*") and the temperature of room thermostat 2 (**TA2**) (if the boiler has one). The burner and the heating pump of circuit 2 (**BC₂**) will begin to function until the installation reaches the selected boiler setpoint temperature (or the temperature on room thermostat 2, if the unit has one). When the temperature of the installation drops below the selected boiler temperature, the burner will start up again, running the heating cycle.

NOTE: When the heating function is disabled, if OFF is selected circuit 2 will also be disabled.

14. ADDITIONAL FUNCTIONS

The **TRO Evolution Accu.** boiler is equipped with an electronic control for efficiently regulating automatic boiler functioning. It also has the following additional control features:

14.1 Pumps anti-block function

This function prevents the boiler circulation pumps from seizing up if they have been out of use for a long period. This system remains enabled while the boiler is plugged into the mains.

14.2 Anti-frost function

This function protects the boiler from freezing up during cold weather. If the boiler temperature drops to below 6 °C, the heating circulation pump will start up. If the boiler temperature continues to drop and reaches 4 °C, the burner will start up, heating the installation. When this function has been activated, it will continue working until the boiler reaches 8 °C. This system remains on standby while the boiler is plugged into the mains.

14.3 Boiler pressure sensor function

This function prevents boiler failure caused by a low water level or excess pressure in the boiler. The pressure is detected by a pressure sensor **(6)**, and its value appears on the control panel display (see "*Digital display*"). If the pressure drops below 0.5 bar, the electronic control blocks boiler functioning and triggers the "**AP**" alarm on the display. If boiler pressure exceeds 2.5 bar, the "**HI**" warning will flash on the display to warn of the excess pressure. If this should occur we recommend calling the nearest **Technical Assistance Service**, and slightly draining the boiler.

14.4 Telephone relay connection

The **TRO Evolution Accu.** boiler is designed to enable a phone relay to be connected for switching the boiler on and off. This feature allows the boiler to be switched on and off remotely, from any location, by means of a phone call. The relay is connected to the boiler via terminal strip **J6** (see "*Electrical Connection Diagram*"). When the telephone relay contact closes the boiler switches on. When the contact opens, the boiler switches off and remains in anti-frost protection and pump anti-block mode.

14.5 Room thermostat connection

The boiler has two terminal strips, **TA₁** and **TA₂**, for connecting room thermostats or room chronothermostats (J5 and J7, see "*Electrical Connection Diagram*"). This allows the heating mode for each circuit installed to be switched off according to the room temperature. To suitably connect them, first remove the bridge joining the terminals of terminal strip **TA₁**, and to connect **TA₂**, simply connect the thermostat to the terminal strip.

Installing a room thermostat will optimise the installation's performance, adapting the heating to the requirements of your home and obtaining enhanced comfort. Also, if the thermostat allows the hours of functioning to be programmed (chronothermostat), it can adapt the heating system to the hours of use of the installation.

14.6 Anti-legionella function (optional)

This optional function prevents the bacteria causing legionnaire's disease from proliferating in the hot water accumulated in the tank. Every 7 days, the temperature of the water in the tank is raised to 70 °C to kill any such bacteria. This function will only run if the boiler is left switched on.


The boiler is supplied with this function disabled. To enable it, carefully read the "*Installation Instructions*" section. We recommend that the operation for enabling this function is carried out by qualified personnel.

14.7 Keypad block function

This function protects the control panel from being accidentally or erroneously pressed while it is being cleaned, by children or by unauthorised persons. When this function is enabled, the electronic control will not react when any of the symbols or touch buttons on the control panel are pressed.

To lock the keypad, keep your finger on the RESET touch button for 5 seconds. The word "**LOC**" will flash on the display until the control panel is unlocked again.

To unlock the keypad, place your finger on the RESET touch button again for 5 seconds. The display will then return to its normal status.



15. E20 REMOTE CONTROL (OPTIONAL)

A remote control (E20) may optionally be supplied together with the **TRO Evolution Accu.** boiler. This remote control can be used to fully operate the boiler from any room in the home it is installed in. The E20 remote control governs the settings of heating circuit 1 and the installation's domestic hot water production (where the case may be).

This remote control allows the hours of home comfort to be programmed for heating circuit 1, adjusting the installation to the particular requirements of the home by measuring the room temperature and consequently adapting the installation temperature. The remote control can also be used to adjust the DHW and heating setpoint temperatures at any time, and for viewing the different boiler operation settings. It also warns of any functioning anomalies affecting the boiler.

The E20 remote control may optionally be connected to an external sensor, for measuring the outside temperature. When this option is installed, the remote control can adjust the home comfort level (circuit 1) according to the weather conditions at each particular time, optimising fuel consumption and heating comfort in the home.

The E20 remote control takes over the control of the boiler when it is connected to it. The different selectable boiler temperatures must be modified using the remote control. It is easy to install, only requiring 2 wires for communication between the boiler and the E20 control. It is connected to the boiler by connecting the two wires on terminal strip **J4** (see "Electrical Connection Diagram"). For correct installation and functioning, carefully read the instructions enclosed with the remote control.

The following sections contain a general explanation of the E20 remote control's different operating modes and options.



TRIANCO

15.1 Functioning without an outdoor sensor

Conventional heating installation (direct circuit)

The maximum temperature for heating circuit 1, the scheduled heating times and the desired room temperatures can be selected on the remote control. The E20 remote control will calculate the boiler temperature required at each particular time, depending on the temperature of the room, and it will activate or disable the heating mode of circuit 1 depending on the heating times and room temperatures programmed.

15.2 Functioning with an external sensor (Optional)

If the E20 remote control is fitted with an outdoor temperature sensor, it can calculate the heating temperature of heating circuit 1 according to the outside weather conditions at each particular time, with optimum adjustment of the heating installation conditions for improved comfort in the home and energy savings.

Conventional heating installation (direct circuit)

The maximum temperature, an operating curve for heating circuit 1 (see instructions enclosed with the E20 remote control) and the desired heating times and room temperatures can all be selected on the remote control. The E20 remote control calculates the required boiler temperature at each particular time, depending on the temperature inside the home and the outside weather conditions, in accordance with the operating curve selected (setting HEATSLOPE 1 on the E20), switching the heating on and off in accordance with the heating times and the room temperatures programmed.

15.3 DHW mode functioning

The E20 remote control can be used to select up to two DHW temperatures and the desired DHW production times. The E20 remote control regulates the DHW tank temperature at each particular time, and enables or disables the DHW function according to the times scheduled.

The E20 remote control also has an option for enabling a function to protect against legionella bacteria (see instructions enclosed with the E20 remote control).

15.4 Telephone relay function

The E20 remote control is designed for connection to an external telephone relay. If a telephone relay is connected to the E20 remote control, the heating mode of heating circuit 1 and the DHW mode can be switched on and off from anywhere in the world, simply by making a telephone call (see instructions enclosed with the E20 remote control).

16. SAFETY CUT-OUTS


The boiler's electronic control system may activate the following safety cut-outs to stop the boiler functioning. When one of these safety cut-outs occurs, the boiler will stop functioning, a cut-out code will flash on the display and the red alarm warning pilot light will flash on the control panel.



If any of the safety cut-outs described below should occur repeatedly, switch off the boiler and call your nearest official technical assistance service.

16.1 Temperature safety cut-out

When this cut-out occurs, the alarm code "EAt" (temperature alarm) will begin to flash on the digital display (19). The burner will switch off and stop heating the installation.



This occurs when the boiler exceeds a temperature of 110 °C. To unblock it, wait until the boiler drops to below 100 °C and press the button on the safety thermostat, located inside the boiler on the underside of the electrical box, after first having removed the button cover.

16.2 Burner cut-out

When this cut-out occurs, the alarm code "EAQ" (burner alarm) will begin to flash on the digital display (19). The burner will switch off and stop heating the installation.



This occurs as a result of an anomaly in the burner (18) or in the fuel installation. To unblock it, press the illuminated button that lights up on the burner.

16.3 Low pressure cut-out

When this cut-out occurs, the alarm code "EAP" (pressure alarm) will begin to flash on the digital display (19). The burner and the boiler circulation pumps will switch off, cutting off the heating and water flow to the installation.



This occurs when the boiler pressure drops to below 0.5 bar, preventing the boiler from functioning when the water is drained from the installation, due to either leakage or maintenance operations. To unlock it, fill the installation again until a pressure of 1 - 1.5 bar appears on the "boiler pressure" setting on the display (19).

17. BOILER MAINTENANCE

To maintain the boiler in perfect working order, a yearly overhaul should be performed by **TRIANCO's authorised personnel**.

17.1 Cleaning the boiler

To keep the boiler in perfect working order, we recommend cleaning the boiler chamber, exhaustion ducts and condenser on a yearly basis. A cleaning brush of a suitable size for cleaning the inside of the exhaustion ducts is supplied with the boiler for this purpose. This brush is located at the rear of the boiler, beside the condenser.

The combustion chamber and exhaustion ducts should not be cleaned using chemical products or hard steel brushes. After any cleaning operation has been carried out, it is important to run several ignition cycles to check all the elements are functioning correctly.

For correct cleaning, the following recommendations should be carefully observed:


Cleaning the boiler body

- Open and remove the outer door of the boiler.
- Remove the burner **(18)** by unscrewing the fixing nut on the top of the burner.
- Remove the combustion chamber door and the exhaustion duct cover, unscrewing the six fixing nuts beside them.
- Clean the exhaustion ducts on the cast iron body, using the cleaning brush supplied with the boiler.
- Clean the boiler combustion chamber. We recommend using a soft brush for scraping the combustion chamber surfaces, and a blower to remove scale.
- After cleaning, replace the combustion chamber door, the exhaustion duct cover, the burner and the outer door of the boiler.

Cleaning the condenser

- Remove the rear extension on the sides of the boiler to access the condenser on the rear of the boiler body.
- Open the top cover of the condenser (1) to access its exhaustion ducts. To open this cover, firstly release the two side closures (7), turn the locking plate (2) anti-clockwise and pull the cover upwards to remove it.
- Remove the fume deflectors (6) inside the fume outlets.
- Clean the exhaustion ducts using the cleaning brush supplied with the boiler. Scale could fall out of the lower condenser cover and come out of the condensation drain, and it is therefore recommendable to pour water into the top of the condenser, for more effective cleaning. This water will be automatically discharged through the condensation drain.
- To clean the outer part of the condenser cylinder, remove the three screws (3) and then remove the metal ring (4). Take out the seal (5) and use the brush to clean it. Then put the components back in place again and replace and tighten the three screws and the metal ring.
- If the lower condenser cover (9) needs cleaning, remove the side cover of the boiler to access it. Firstly remove the bracket (8) holding it in place and pull on it to open it. Then pull the lower cover down to open and clean it.

- After cleaning, replace the fume deflectors, the top condenser cover and the top outer cover of the boiler. Then put the cleaning brush back inside the boiler.
- The condensation siphon should be cleaned once a year. To do this, remove it and wash it in soapy water. Replace the siphon after cleaning.



17.2 Anti-frost protection

The **TRO Evolution Accu.** boiler has a function for preventing frost damage to the installation. This will function as long as the appliance remains plugged into the mains. Despite this function, and particularly in areas with very cold weather, we recommend taking precautions in order to prevent damage to the boiler. It is advisable to add anti-freeze to the water in the heating circuit. If the boiler is to be out of use for long periods of time, we recommend **draining all the water and leaving it empty.**

17.3 Boiler water characteristics

In areas with water hardness of over 25-30°F, treated water must be used in the heating installation to avoid any scale deposits on the boiler. It should be noted that even a few millimetres of scale will greatly reduce the boiler's heat conductivity, causing a major drop in performance.

Treated water must be used in the heating circuit in the following cases:


- Very large circuits (containing a large amount of water).
- Frequent filling of the installation.

If repeated partial or total draining of the installation is necessary, we recommend filling it with treated water.

18. CIRCULATING PUMPS FLOW CURVES


The hydrodriving pressure available in the installation at the boiler output can be deduced from the following graphs, having taken the boiler pressure drop into account.

18.1 Characteristic curves of the pump



18.2 Regulation of the circulation pump


To regulate the speed of the circulation pump BC1 you should navigate to the "UB" parameter by touching MODE button and touch ON button (22) to access it. Once inside the setting, using the jog dial on the right side of the display (24) the value changes. After selecting the desired speed, touch the ON touch button to record the value and exit the parameter "UB".




WARNING: Any interference in the operation and installation of the heating circuit must be done by authorised personnel, always respecting current legislation and installation safety standards, both national and local level.

18.3 Pressure drop

TRO Evolution 30 Inc DHW Accu.:




TRO Evolution 40 Inc DHW Accu.:



19. DIMENSIONS

19.1 TRO Evolution Accu.



IC: Heating outlet.

IC': Optional heating outlet.

RC: Heating return.

EAS: DHW inlet.

IAS: DHW outlet.

VS: Safety valve.

SC: Condensates drainage, 1" H.

BW: Balanced cold take off

EA: Combustion air inlet, Ø80.

SH: Flue gases outlet Ø100.


TR: Optional DHW recirculation connection

MODEL	IC/IC' RC	EAS IAS	BW	DIM. L
TRO Evolution 20 Inc DHW Accu.	3/4"M	3/4"M	3/4"M	910
TRO Evolution 30 Inc DHW Accu.	3/4"M	3/4"M	3/4"M	910
TRO Evolution 40 Inc DHW Accu.	1"M	3/4"M	3/4"M	950

20. TECHNICAL DATA

TRO EVOLUTION ACCU.			20	30	40
Boiler type	-		Condensation		
			Heating + DHW tank		
Rated heat output	P_{rated}	kW	19	30	40
Useful heat output	P_4	kW	19,0	28,7	38,7
Useful heat output (30%)	P_1	kW	6,1	8,5	12,4
Seasonal space heating energy efficiency	η_s	%	90	91	92
Useful efficiency	η_4	% (PCI)	96,55	97,96	97,29
		% (PCS)	91,04	92,38	91,74
Useful efficiency (30%)	η_1	% (PCI)	103,82	103,45	104,15
		% (PCS)	97,90	97,55	98,21
Auxiliary electricity consumption at full load	e_{lmax}	kW	0,226		
Auxiliary electricity consumption at part load	e_{lmin}	kW	0,078		
Auxiliary electricity consumption in standby mode	PSB	kW	0,001		
Standby heat loss	P_{stby}	kW	0,127	0,135	0,17
Emissions of nitrogen oxides	NOx	mg/kWh	92	118	119
Declared load profile	-		XXL		
Water heating energy efficiency	η_{wh}	%	71	68	67
Daily electricity consumption	Q_{elec}	kWh	0,595	0,533	0,402
Daily fuel consumption	Q_{fuel}	kWh	35,087	36,708	37,890
DHW storage tank capacity	Lts		130	130	130
DHW production in 10 min. $\Delta t=30^{\circ}\text{C}$	Lts		275	321	321
DHW production in 1 hour $\Delta t = 30^{\circ}\text{C}$	Lts		575	846	846
DHW recover time from 35 to 58 °C			8		
Heating temperature range	°C		OFF, 30-85		
DHW temperature range	°C		OFF, 15-65		
Heating security maximum temperature	°C		110		
Heating security maximum pressure	bar		3		
DHW security maximum pressure	bar		6		
Heating expansion vessel capacity	Lts		8	8	12
Boiler water capacity	Lts		14	19,2	23,2
Water pressure drop	mbar		96	163	272
Flue gases temperature	°C		69	67	83
Flue gases volume	m^3		0,094	0,114	0,175
Maximum flue gases flow	Kg/s		0,0085	0,0132	0,0186
Flue gases pressure drop	mbar		0,20	0,20	0,21
Combustion chamber lenght	mm		220	300	400
Combustion chamber type	-		wet, three smoke steps		
Burner type	-		ON/OFF		
Electric power	-		~220-230 V - 50 Hz - 200 W		
Weight	Kg		235	265	285

21. ELECTRICAL DIAGRAM



TS: Security thermostat.

TH: Fumes thermostat.

SP: Pressure sensor.

R: Phone relay

J6: Phone relay connector.

J8: Communication connector cards.


S1: Boiler model selector

S2: Floor heating selection switches.

22. ELECTRICAL CONNECTION DIAGRAM

To carry out the connection of the diverse options and components of this model, it incorporates a series of removable connectors located under of the main board. For their correct connection, follow the instructions of the following pictures carefully:

22.1 TRO Evolution Accu.



F: Phase.

N: Neutral.

bc7: Burner terminal n. 7.

Q: Burner.

BV: DHW charge pump.

BC₁: Heating circuit N. 1 circulating pump.

BC₂: Heating circuit N. 2 circulating pump.

E20: Remote control E20 (optional).

TA₁: Heating circuit N. 1 room thermostat.

TA₂: Heating circuit N. 1 room thermostat.

PWM_c: Heating PWM cable.

Sa: DHW temperature sensor.

Sc: Boiler temperature sensor.

J1: Power supply connector.

J2: Components connector.

J3: Sensor connector.

J4: Remote control connector.








J5: Room thermostat N. 1 connector.


J6: Telephone relay connector.

J7: Room thermostat N. 2 connector.

23. ALARM CODES

The **TRO Evolution Accu.** boiler has an electronic circuit that performs continuous self-testing to detect any operating failures in the boiler. When the electronic control detects malfunctioning, this is indicated by an alarm code flashing on the display. The following list describes the alarm codes that may appear:

CODE	ALARM	DESCRIPTION
	Pressure	The pressure in the installation has dropped to below 0.5 bar. The boiler will cut out. To unblock it, fill the installation at a pressure of 1 - 1.5 bar. This alarm may be set off due to the water having been drained from the boiler or leakage in the installation. If this alarm occurs repeatedly, you should contact the nearest official technical assistance service.
	Temperature	The boiler has exceeded the safety temperature of 110 °C. The boiler will cut out. To unblock it, press the safety thermostat button when the temperature has dropped. If this alarm occurs repeatedly, you should contact the nearest official technical assistance service.
	Burner	The burner has cut out. To unblock it, press the illuminated button on the burner (18) . This alarm is set off when there is a functioning anomaly in the burner or the fuel installation. If this alarm occurs repeatedly, you should contact the nearest official technical assistance service.
	Boiler sensor	The boiler sensor (15) is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
	DHW sensor.	The tank DHW sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
	SRX2/EV flow sensor (only with SRX2/EV kit)	The underfloor heating sensor is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.
	Pressure sensor	The pressure sensor (10) is damaged or disconnected. Contact your nearest official technical assistance service to have it replaced.

	Overpressure	<p>This indicates that the water pressure in the boiler is over 2.5 bar, warning that the installation is in overpressure status. Boiler functioning will NOT cut out.</p> <p>To restore normal boiler functioning, drain the boiler until it reaches a pressure of 1 – 1.5 bar. If this warning occurs repeatedly, you should contact the nearest official technical assistance service.</p>
---	--------------	---

NOTE: It will be very useful for the technical assistance service if you can inform them of the alarm code that has appeared on call-out.

24. BURNER

24.1 Assembly

Attach the burner support to the boiler. Attach the burner to the support. This provides the correct inclination of the flame tube towards the combustion chamber. Assemble the suction and return pipes, inserting into the suction pipe the oil filter.

24.2 Burner start up

The "**Domestic**" burner is equipped with a self-aspirating pump, which permits aspiration of oil from the deposit located on a lower level than the burner, as long as the negative pressure measured with a vacuum gauge at the pump does not exceed 0.4 bar (30 cmHg).

Make sure there is oil in the deposit, the oil valves are open and power is reaching the burner. Connect to the main switch. Unscrew the air release valve (Pressure gauge input). Then, when the electro valve is opened, remove the flame sensor from its position and move it near to a light source until the oil arrives. Disconnect the burner and screw in the release valve.

24.3 Combustion adjustment

As each installation is different, and has a unique combustion circuit, it is essential that combustion conditions at each boiler are adjusted. For the **guarantee to be valid**, burner adjustment must be conducted by **TRIANCO's Official Technical Assistance Service**.

Observe the flame. If it lacks air it will be dark and produce fumes rapidly blocking the flues.

On the contrary, if there is too much air it will be white or bluish white, yielding poor performance and in not comply with anti pollution regulations, also the excess air may impede ignition.

The flame should be an orange colour.


If due to the nature of the boiler it were difficult or impossible to view the flame, air can be regulated by observing the fume exhaust from the uptake; if it is dark air needs to be increased to the burner, if it is very white air must be reduced until no fumes are visible.

If you have the equipment to verify combustion gas composition, that would be the best way of adjusting the flame, but if you do not have one to hand for the time being follow the instructions above.

To adjust the air and burner line conditions, carefully follow the following instructions:


Primary air adjustment

To adjust primary air, use a 6mm Allen key, and rotate as indicated in the figure. Clockwise to increase airflow and anti-clockwise to reduce airflow.




Combustion adjustment

To adjust the combustion line loosen lock screw **"BL"**: Rotate adjuster **"RL"**, clockwise for more AIR and anti-clockwise for less AIR. After adjustment tighten lock screw **"BL"**.



Correct electrode position

To ensure proper ignition of the **"Domestic"** burner the measures indicated in the figure must be respected. Also, ensure that the electrode fixing screws have been attached to the electrode before reinstalling the flame pipe.






TRIANCO


24.4 Oil pressure adjustment

To adjust oil pump pressure, turn screw (1) clockwise to increase and anti-clockwise to reduce.

- 1 - Pressure adjustment.
- 2 - Vacuum gauge input
- 3 - Electrovalve.
- 4 - Pressure gauge input
- 5 - Nozzle outlet.
- 6 - Return.
- 7 - Suction.




24.5 Pipe preparation




24.6 Oil supply piping diagrams

The diagrams and tables below correspond to installations without reductions and with a perfect hydraulic seal. It is recommended to use copper pipes. A pressure drop of 0.4 bar (30 cmHg) must not be exceeded.

Intake installation



Charging installation



1,0	20	40
1.5	40	80
2.0	60	100

Intake installation

H (m)	Pipe length	
	int.Ø 8 mm.	int.Ø 10 mm.
0.0	25	60
0.5	21	50
1.0	18	44
1.5	15	38
2.0	12	26
2.5	10	26
3.0	8	20
3.5	6	16

Charging installation

H (m)	Pipe length	
	int.Ø 8 mm.	int.Ø 10 mm.
0.5	10	20

WARNING: Check periodically the flexible pipes conditions. Using kerosene, they have to be replaced at least every 2 years.


24.7 Technical specifications

MODEL		D-3	D-4
Minimum consumption	Kg/h	1,5	2,3
Maximum consumption	Kg/h	3	4.65
Minimum power	kW	17,7	27,2
Maximum power	kW	35,5	55,2
Motor power at 2800 rpm.	W	200	
Adjustment type		ON/OFF	
Voltage		220 V - 50 Hz	
Weight	Kg	12,5	
Preheater		YES	



TRIANCO

24.8 Operating curves



24.9 Nozzles


TRO Evolution Accu. boilers are supplied with the burner fitted, together with its corresponding nozzle and a standard pre-adjustment. The following table shows the nozzles and adjustments for each particular model:

MODEL	Nozzle	Burner pressure (bar)	Air adjustment	Line adjustment
TRO Evolution 20 Inc DHW Accu.	0,45 80° H	10	7	1
TRO Evolution 30 Inc DHW Accu.	0,65 60° H	10	3,5	1
TRO Evolution 40 Inc DHW Accu.	1,00 45° H	9	3,5	1

24.10 Oil flow versus nozzle and pump pressure

Nozzle GPH	Oil Kg/h		Kerosene Kg/h	
	9 bar	10 bar	9 bar	10 bar
0,45	1,58	1,67	1,4	1,5
0,65	2,29	2,42	2,02	2,17
1,00	3,53	3,72	3,12	3,35

24.11 Electrical connection diagram



TC: Boiler thermostat.

TS: Safety thermostat.

F: Fuse.

LB: Lock light.

FR: Flame sensor.

TR: Transformer.

MB: Pump motor.

EV: Pump electrovalve.

RP: Pre-heater resistance.

Ph: Phase.


N: Neutral.

TP: Pre-heater thermostat.

24.12 Quick connector

To connect and disconnect the red oil entry pipe to the nozzle, proceed as follows:


- Press the yellow ring on the connector in the direction indicated by the arrow, and at the same time pull the red pipe.



24.13 Burner control operating sequence

The burner's LMO control box has a reset button which is the key element for resetting the burner control and activating/deactivating the diagnosis functions.

The multi-colour LED on the reset button is the indicator for visual diagnosis. The button and the LED are located under the transparent cover of the reset button. During normal functioning, the various operating statuses are indicated in the form of colour codes (see the colour code table below). During ignition, the indication is as shown in the following table:



Colour code table for multi-colour indicator lights (LEDs)		
Status	Colour code	Colour
Wait time «tw», other standby statuses	○.....	Off
Fuel pre-heater on	●.....	Yellow
Ignition phase, controlled ignition	●○●○●○●○●○●○	Flashing yellow
Functioning, flame OK	□.....	Green
Functioning, flame not OK	□○□○□○□○□○	Flashing green
External light during burner ignition	□▲□▲□▲□▲□▲	Red/green
Undervoltage	●▲●▲●▲●▲●	Yellow/red
Failure, alarm	▲.....	Red
Error code output (see «Error code table»)	▲○ ▲○ ▲○ ▲○ ▲○	Flashing red
Interface diagnosis	▲▲▲▲▲▲▲	Flashing red light

..... Steady light

○ Off

▲ Red

● Yellow

□ Green

25. FAILURES

This section provides an index of the most common failures in both the burner and boiler.

Burner error code

We have already mentioned that the burner is equipped with a cut-out system, indicated by the reset button light. It may cut out accidentally, and in this case the steady red light on this button will come on. You may unblock it by pressing the button for approx. 1 second. When the burner is blocked and the steady red light is on, visual failure diagnosis may be activated, in accordance with the error code table. To enter visual failure diagnosis mode, hold down the reset button for at least three seconds.

Error code table		
Red flashing LED code	"AL" on term. 10	Possible cause
Flashes 2 times	On	No flame established when ignition safety time ends. - Fuel valves defective or dirty - Flame detector defective or dirty - Burner maladjustment, no fuel - Ignition unit defective
Flashes 4 times	On	External light during burner ignition
Flashes 7 times	On	Excessive flame loss during functioning (limited number of repetitions) - Fuel valves defective or dirty - Flame detector defective or dirty - Burner maladjustment
Flashes 8 times	On	Supervision of fuel pre-heater time
Flashes 10 times	On	Cabling fault or internal failure, output contacts, other failures

During the failure diagnosis time, the control outputs are disabled and the burner remains off. To exit failure diagnosis and activate the burner again, reset the burner control. Hold down the reset button for approx. 1 second (<3 s).

Boiler failures:

FAILURE	CAUSE	REMEDY
RADIATOR DOES NOT HEAT	- The pump does not rotate - Air in hydraulic circuit	Unlock the pump Drain the installation and boiler (The air vent plug is always to be loose)
EXCESSIVE NOISE	- Poorly-adjusted burner - There is no sealing on the uptake - Unstable flame - Uptake with no thermal insulation	Adjust properly Eliminate the leakage Check the burner Insulate properly


Circulating pump alarms

The high efficiency pumps include a Led (light) which displays their status.

PUMP LIGHT	DESCRIPTION	STATUS	CAUSE	SOLUTION
It is lit green	The pump is functioning	The pump operates according to its setting	Standard functioning	
It flashes green	Standby mode (PWM version)	The pump is in standby mode		
It flashes red/green	The pump is ready for service but is not functioning	The pump will start up again automatically once the error has been solved	1. Low voltage $U < 160 \text{ V}$ or Excess voltage $U > 253 \text{ V}$	1. Check the power supply $195 \text{ V} < U < 253 \text{ V}$
			2. Excess temperature of the module: the temperature of the motor is too high	2. Check the room temperature and that of the fluid
Flashes red	The pump is out of order	The pump is stopped (blocked)	The pump does not start up automatically.	Change the pump. Please contact your nearest official technical assistance service to have it replaced
Light off	There is no power supply	The electrical system is not receiving power supply	1. The pump is not connected to the power supply	1. Check the connection of the cable
			2. The LED is faulty	2. Check if the pump works
			3. The electrical system is Faulty	3. Change the Pump. Change the pump. Please contact your nearest official technical assistance service to have it replaced

26. SPARE PARTS LIST


Boiler





TRIANCO

Electrical main board




<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>	<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>
1	SEPO000590	Door	23	CTOE000012	Fixing clip
2	SEPO000589	Front panel	24	CFOV000068	D.H.W. expansion vessel
3	CFER000059	Automatic closure	25	CFOV000148	Heating pump 20/30 HFDX
4	CVAL000034	½ drain tap with chain		CFOV000149	Heating pump 40 HFDX
5	CFOV000163	Disconector Robofil	26	SEPO000585	Right side panel 20/30 HFDX
6	CFOV000148	Pump		SEPO001074	Right side panel 40 HFDX
7	CFER000051	Extraflex 80 extendable tube		SEPO000584	Left side panel 20/30 HFDX
8	CFUC000052	Cast iron Burneo support door		SEPO001073	Left side panel 40 HFDX
9	CFUC000053	Cast iron vent cover	27	SELEEVO022	Electrical board
10	CVAL000004	½ 3kg. Safety valve with man. pt.	28	CELC000294	Control panel embellisher
11	CFUR000018	Manifold 40 FDX	29	COTR000046	Main board glass
	CFUR000019	Manifold 20/30 HFDX	30	CMAZ000128	Cable harness
12	CFOV000032	7.5l. expansion vessel	31	CELC000022	Safety thermostat 110° 1,5m
13	CELC000252	Pressure transducer	32	CELC000036	Weidmuller strip 3 poles
14	SEPO000586	Side extension HFDX	33	CELC000234	Temp. Evolution sensor 0,90 mts
15	SEPO001002	Rear panel HFDX	34	CELC000211	Electronic control sensor 1,5 mts.
16	SEPO000588	Rear cover	35	CEXT001024	Connection cover
17	CVAL000055	Inlet group	36	CELC000358	Power supply card
18	SEPO000597	Roof 20/30 HFDX	37	SEPO001303	Panel fastening
18	SEPO001080	Roof 40 HFDX	38	CELC000255	Pressure sensor cable
19	CFOV000024	3/8 PURGOMAT drain valve	39	SEPO001948	Drawer
20	CVAL000051	T & P safety valve	40	SEPO001304	Drawer cover
21	RDEP000000	130l. stainless steel tank	41	CELC000298	Electronic cards cable
22	CFER000048	Spring closure	42	CELC000360	Display card



TRIANCO

<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>	<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>
43	SCHA008320	Soporte display	44	CELC000022	Flue gas thermostat

Burner



<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>	<u>Pos.</u>	<u>Código</u>	<u>Denominación</u>
1	CFER000032	Cable gland	19	CQUE000191	Oil hose
2	CFER000033	Cable gland	20	CQUE000055	Oil filter
3	CQUE000027	Preheater cable	21	CTOR000007	Elbow connector
4	CTOE000063	Burner line D3	22	CQUE000062	Oil pump Suntec
5	CQUE000155	Turbulator disc D3		CQUE000088	Oil pump Danfoss
	CQUE000013	Turbulator disc D4	23	CQUE000056	Valve coil Suntec
6	CQUE000019	Set of electrodes		CQUE000089	Valve coil Danfoss
7	CQUE000044	Fan	24	CQUE000054	Valve coil cable Suntec
8	CQUE000095	Air adjustment support		CQUE000124	Valve coil cable Danfoss
9	CTOE000064	Air adjustment screw	25	CTOE000065	Counter thread
10	CQUE000151	Air adjustment plate D3	26	CQUE000004	Motor pump coupling
	CQUE000152	Air adjustment plate D4	27	CQUE000102	Motor
11	CQUE000018	Manifold	28	CQUE000094	Motor support
12	CQUE000173	Flange seal	29	CQUE000192	Nozzle OD-H 0,45 – 80° (D3)
13	SATQUE0001	Flange		CQUE000077	Nozzle OD-H 0,65 – 65° (D3)
				CQUE000079	Nozzle OD-H 1,00 – 45° (D4)
14	CQUE000158	Support seal	30	CQUE000061	Preheater
15		D3 burner shaft	31	CQUE000096	Line cover
		D4 burner shaft	32	CQUE000149	Photocell support
16	CQUE000129	Control box base	33	CQUE000156	Photocell
17	CQUE000169	Control box	34	CTOE000054	Line adjustment nut
18	CQUE000005	Transformer	35	CTOR000006	Straight connector

27. WARRANTY CONDITIONS

TRIANCO's **commercial guarantee** covers the standard functioning of the products manufactured by **Domusa Calefacción S.Coop.**, in accordance with the following conditions and time periods:

1. This **commercial guarantee** is valid for the following periods, as from the **commissioning** date:

2 Years for electric and hydraulic elements: pumps, valves, etc.

12 Years for heat exchangers.

10 Years for domestic hot water tanks.

After these 2 years have elapsed and until the end of the guarantee period, labour costs and call-out charges will be payable by the user.

2. The annual maintenance is not included in the terms of this guarantee.

3. The commissioning and annual maintenance must be carried out by personnel authorised by **TRIANCO**.

4. The **commercial guarantee** will be null and void in the following cases:

- If the annual maintenance by personnel authorised by **TRIANCO** has not been carried out.
- If the boiler has not been installed in accordance with the applicable laws and regulations for this type of appliance.
- If the boiler has not been registered on the website domusateknik.com, immediately after its installation.

Failures due to misuse or incorrect installation, use of non-suitable electrical power or fuel, supply with water with physical or chemical properties causing incrustation or corrosion, incorrect handling of the appliance, lack of pressure on the primary water circuit and, in general, for any reason beyond **TRIANCO's** control, are excluded from this guarantee.

This guarantee does not affect the consumer's rights as stipulated by law.



This image shows a full page of white paper with horizontal dotted lines. The lines are evenly spaced and run across the width of the page, providing a guide for handwriting or typing. There are no margins, text, or other markings on the page.



TRIANCO

TR ENGINEERING LTD

Thorncliffe, Chapeltown,
Sheffield, S35 22PH

Tel: (0114) 2572300

Fax: (0114) 25714199

www.trianco.co.uk

Copyright in this brochure and the drawings and illustrations contained within are vested in TR Engineering Ltd and neither the brochure or any part thereof may be reproduced without prior written consent.

TR Engineering's policy is one of continuous research and development. This may necessitate alterations to this specification. Instructions correct at time of going to print.



CDOC001626

04/17